IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed, including the following:

- **Read all instructions.**
- **Do not touch hot surfaces. Use handles or knobs.**
- **To protect against electrical shock, do not immerse cord, plug, or appliance in water or other liquid.**
- **Close supervision is necessary when any appliance is used by or near children.**
- **Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.**
- **Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Return appliance to the nearest authorized KRUPS Service Center for examination, repair or adjustment (see Guarantee of Performance).**
- **The use of accessory attachments not recommended or sold by KRUPS may cause injuries.**
- **Do not use outdoors.**
- **Do not let cord hang over edge of table or counter, or touch hot surfaces.**
- **Do not place on or near a hot gas or electric burner or in a heated oven.**
- **Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.**
- **To disconnect remove plug from wall outlet.**
- **Do not use appliance for other than intended use.**
- **Do not use metallic fasteners to hold the waffles in place. Sharp utensils should not be used.**
- **Always check that the voltage indicated on the identification panel matches that of your electrical installation.**
- **Any error in connecting the appliance invalidates the guarantee.**

•Position the appliance on a flat, heat resistant surface.

•Do not leave or use the appliance in a damp area.

•Do not touch the non-stick plates when in use.

SAVE THESE INSTRUCTIONS

CAUTION

This appliance is for household use. Any servicing other than cleaning and user maintenance should be performed by the nearest authorized KRUPS Service Center (see Guarantee of Performance).

• Do not immerse appliance in water.

•To reduce the risk of fire or electric shock, do not open the appliance. No user serviceable parts inside. Repair should be done by an authorized KRUPS Service Center only.

SPECIAL CORD SET INSTRUCTIONS

Regarding your Cord Set:

A. A short power-supply cord is to be provided to reduce the risk resulting from becoming entangled in or tripping over a longer cord.

B. Extension cords are available and may be used if care is exercised in their use.

C. If an extension cord is used, (1) the marked electrical rating of the extension cord should be at least as great as the electrical rating of the appliance, (2) the cord should be arranged so that it will not drape over the counter top or table top where it can be pulled on by children or tripped over unintentionally.

D. This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way.

Description

a Non-stick Plates
b Insulated Cool-touch handles
c On/Off indicator light
d Ready light
e Thermostat control

Before using your appliance for the first time

- Clean the plates with a damp sponge and wipe dry.
- Lightly coat the waffle plates with vegetable oil or non-stick cooking spray, then close the appliance and plug it in.

The indicator lights (c) and (d) will come on.

- Leave for a few minutes to remove the "new" smell.

Using the Krups waffle maker

- Close the appliance and plug into outlet. Both the indicators (c) and (d) will illuminate **(1)**.
- Choose the temperature level on the thermostat (e) (level 1 = the lowest setting 6 = the highest setting) **(2)**.

When the appliance reaches the required temperature, the ready light (d) will go out **(3)**.

- Open the appliance and pour the waffle batter in the center of the plate making sure you do not overfill **(4)**.
- Close the lid immediately, making sure the lower plates are covered **(5)**.
- IMPORTANT - Do not lock the handle during the cooking to provide extra space for the waffle-batter to rise .

During the cooking, the ready light (d) will turn on and off to guarantee a constant cooking temperature. If the temperature is too high or too low during the cooking cycle,

you can change the temperature level using the thermostat.

Practical Hints

- The cooking time is around ? ? ? minutes, and varies according to the type of batter being used.
- It is recommended to adapt cooking with the thermostat according to your own taste. Cooking times given are approximations only.
- When cooking is complete, remove the waffle using a spatula **(6)**.
- IMPORTANT - Avoid the use of metallic or sharp utensils, as they will damage the non-stick coating of the plates.
- If you wish to make more waffles, close the lid and wait until the ready light (d) goes off before cooking a new batch.
- If you wish to have darker waffles, choose a higher level on the thermostat or increase the cooking time.
- After use, unplug the appliance and allow it to cool

Cleaning

- Always disconnect the appliance before cleaning, and leave to cool.
- Do not place the appliance in water or under running water.
- To clean the exterior, wipe with a damp cloth, being careful that liquids do not enter between the plates.
- To clean the interior, wipe the toasting plates with a damp cloth, some dishwashing soap may be used, then wipe with a wet sponge and dry carefully.

If baked-on batter remains on the plates, we recommend using vegetable oil to soften the remaining batter and wait 5 minutes before wiping it off.

- Do not use metal scouring pads, scouring powders, or abrasives when cleaning the interior or exterior of this appliance.

Storage:

Close the lid, wrap the cord around the appliance and store vertically to save space **(7)**.

What to do if your appliance does not work

- Check that the appliance is plugged in correctly.

If your appliance still does not work, consult a KRUPS Authorized Service Center (see list in KRUPS service booklet)

Limited One Year Warranty

Your KRUPS #FDD5 is covered by the following warranty :

If within one year from date of purchase this KRUPS product fails to function because of defects in materials or workmanship, KRUPS North America will, at its option, repair or replace the unit with out charge, provided the owner has a proof of date of purchase.

This warranty will be void if malfunction was caused by damage to the product by accident, misuse, use on frequency or voltage other than marked on the product and/or described in the instructions, abuse including tampering, damage in transit, or use for commercial purposes. This warranty gives you specific legal rights, and you may also have other rights which may vary from state to state.

GUARANTEE OF PERFORMANCE

This fine KRUPS product is manufactured according to a rigid code of quality standards, and, with minimum care, should give years of service. However, should the need arise for repairs or for replacement parts within or after the warranty period, please call our CONSUMER SERVICE DEPARTMENT:

USA :(800) 526-5377
24-hours a day, 7 days a week

CANADA : (905) 669-0114
Monday-Friday 8 :00 a.m. – 4 :30 p.m.

You will be provided with specific instructions on how to get your product repaired, as well as the name and address of your nearest authorized KRUPS Service Center.

The department will also be able to answer any general product questions you may have.

Before calling the Consumer Service Department, please have the model number of your KRUPS appliance available.

You must have this information before calling our Consumer Service Department so that we may better answer your questions. The model number can be located by looking at the bottom of your appliance.

This product is Model #FDD5

Any general correspondance can be addressed to:

USA :KRUPS North America, Inc.
P.O. Box 3900
Peoria, IL 61612

CANADA : KRUPS SERVICE
20 Caldari Rd.
Concord, Ontario
L4k 4N8

CONSIGNES DE SECURITE IMPORTANTES

Lorsque vous utilisez des appareils électriques, des mesures de sécurités de base s'imposent y compris les mesures suivantes:

- **Lisez toutes les instructions .**
- **Ne touchez pas de surfaces chaudes. Utilisez les poignées et les boutons.**
- **Afin de prévenir les risques de chocs électriques, ne plongez pas le cordon, les fiches ou l'appareil dans de l'eau ou tout autre liquide.**
- **Une surveillance étroite s'impose si l'appareil est utilisé par des enfants ou à leur proximité.**
- **Débranchez l'appareil de la prise quand il n'est pas utilisé et avant de le nettoyer.**
- **Laissez-le refroidir avant de poser ou de retirer des pièces, et avant de le nettoyer.**
- **N'utilisez aucun appareil électrique si la fiche ou le cordon sont endommagés, si l'appareil ne fonctionne pas comme il faut, s'il est tombé ou a été endommagé de quelque façon que ce soit. Dans ces cas, retournez l'appareil au centre de service autorisé KRUPS le plus proche pour le faire examiner, réparer ou régler (Voir " Garantie de rendement ").**
- **L'utilisation d'accessoires non recommandés ni vendus par KRUPS peut causer des blessures.**
- **N'utilisez pas l'appareil à l'extérieur.**
- **Ne laissez pas le cordon pendre le long du bord de la table ou du comptoir, ni toucher une surface chaude.**
- **Ne placez pas l'appareil sur un élément à gaz ou électrique chaud, ni à proximité de celui-ci, ni dans un four chaud.**
- **Faites très attention lorsque vous déplacez un appareil contenant une préparation chaude, de l'eau ou autres liquides chauds.**
- **Pour débrancher ou arrêter l'appareil, retirez la fiche de la prise murale.**
- **Utilisez l'appareil aux seules fins prévues.**
- **N'utilisez pas d'ustensiles métalliques pour maintenir les préparations en place. N'utilisez pas d'ustensiles aiguisés.**

- **Vérifiez que la tension d'alimentation de votre appareil corresponde bien à celle de votre installation électrique.**
- **Toute erreur de branchement annule la garantie.**
- **Placez l'appareil sur un plan de travail stable et résistant à la température.**
- **Ne rangez ou n'utilisez pas l'appareil dans un environnement humide.**
- **Ne touchez pas les plaques anti-adhérentes lorsque l'appareil est en fonctionnement.**

CONSERVEZ CES INSTRUCTIONS

MISE EN GARDE

Cet appareil est destiné à un usage domestique exclusivement. Toute manipulation autre que le nettoyage, ainsi que la réparation de l'appareil doivent être effectuées auprès du centre de service agréé KRUPS le plus proche (voir Garantie de rendement).

- **Ne plongez pas l'appareil dans l'eau.**
- **Afin de réduire tout risque d'incendie ou de choc électrique, ne démontez pas l'appareil. Aucune pièce n'est réparable par le consommateur. Toute réparation doit être effectuée par un centre de service agréé KRUPS.**

INSTRUCTIONS SPECIALES POUR LE CORDON

Au sujet du cordon :

A. Un cordon d'alimentation court fourni avec l'appareil permet de réduire le risque de trébucher sur un cordon long ou de l'emmêler.

B. Des rallonges sont disponibles et vous pouvez les utiliser, à condition de faire preuve de prudence.

C. Si vous utilisez une rallonge : (1) la puissance nominale qui est indiquée doit être au moins égale à la puissance nominale de l'appareil ; (2) si l'appareil est mis à la terre, la rallonge doit être à 3 fils dont un de terre, et (3) le cordon, plus long, ne doit pas pendre du comptoir ni de la table, car des enfants pourraient le tirer et pourraient trébucher non intentionnellement.

D. Cet appareil est doté d'une fiche polarisée (une lame est plus large que l'autre). Par mesure de sécurité, cette fiche ne peut se brancher que d'une seule façon. S'il vous est impossible de l'insérer dans la prise, inversez-là. Si c'est toujours impossible, faites appel à un électricien qualifié. N'essayez pas de modifier ce dispositif de sécurité.

Description

a Plaques avec revêtement anti-adhérent
b Poignée thermo-isolante
c Voyant de mise sous tension
d Voyant de régulation
e Bouton thermostat

Avant une première utilisation

- Nettoyez les plaques avec une éponge humide rincez-les et séchez-les.
- Après avoir légèrement huilé les plaques, fermez l'appareil et branchez-le. Les voyants (a) et (b) s'allument.
- Laissez chauffer quelques minutes pour éliminer l'odeur de neuf.

Mise en service

- Fermez l'appareil et branchez-le. Les voyants (c) et (d) s'allument **(1)**.
- Choisissez le niveau de dorage souhaité à l'aide du thermostat (e) (position 1-6) **(2)**.
- Lorsque l'appareil atteint la bonne température, le voyant de régulation (d) s'éteint **(3)**.
- Ouvrez l'appareil et versez la pâte à gaufre au centre de la partie creuse de la plaque en prenant garde de ne pas déborder. **(4)**.
- Fermez immédiatement l'appareil à l'aide de la poignée de façon à ce que la pâte soit répartie uniformément sur toute la surface **(5)**.
- Ne maintenez pas la poignée de l'appareil pendant toute la cuisson pour permettre à la pâte de gonfler.

Remarque : Durant la cuisson, le voyant de régulation (d) s'allume et s'éteint régulièrement pour assurer une température de cuisson constante. Vous pouvez de même à tous moments pendant la cuisson régler le thermostat si vous jugez que la température est insuffisante ou au contraire trop élevée.

- Le temps de cuisson est d'environ ? ? ? minutes et varie en fonction de la composition de la pâte.

Dans tous les cas, il est conseillé de contrôler le degré de cuisson avec le thermostat en fonction de vos goûts. Les quantités et les temps sont donnés à titre indicatif.

- La cuisson terminée, retirez la gaufre à l'aide d'une spatule **(6)**.
- Evitez l'emploi d'ustensiles métalliques et coupants, car il pourraient endommager le revêtement des plaques.
- Si vous désirez à nouveau faire des gaufres, fermez le couvercle et attendez que le voyant de régulation (d) s'éteigne avant de commencer une nouvelle cuisson.
- Si vous souhaitez obtenir des gaufres plus dorées, choisissez une position supérieure sur le thermostat ou augmentez votre temps de cuisson.
- Après utilisation, débranchez l'appareil et laissez-le refroidir.

Nettoyage

- Avant de nettoyer l'appareil, débranchez-le et laissez-le refroidir .
- Ne mettez jamais l'appareil dans l'eau ou sous l'eau courante.
- Pour nettoyer l'extérieur de l'appareil, utilisez une éponge humide et essuyez soigneusement.
- Pour nettoyer la plaque, utilisez une éponge humide avec du produit à vaisselle. Rincez-la et essuyez-la soigneusement.

S'il reste de la pâte cuite sur la plaque, nous vous conseillons d'utiliser de l'huile végétale pour la ramollir et d'attendre 5 minutes avant de l'enlever.

- N'utilisez jamais de tampon abrasif ni de poudre à récurer.

Rangement

- Enroulez le cordon autour de l'appareil et rangez l'appareil verticalement pour gagner de la place **(7)**.

Si votre appareil ne fonctionne pas que faire ?

• Vérifiez le branchement.

Votre appareil ne fonctionne toujours pas? Adressez-vous à un centre service agréé Krups (voir liste dans le livret service).

GARANTIE DE RENDEMENT

Cet appareil KRUPS de qualité est fabriqué suivant un code strict de normes de qualité et, avec un minimum de soin, devrait vous donner satisfaction pendant de longues années. Toutefois, si des réparations ou des pièces de rechange devaient se révéler nécessaires pendant ou après la période visée par la garantie, veuillez téléphoner à notre SERVICE A LA CLIENTELE :

USA :(800) 526-5377

24 heures sur 24, 7 jours sur 7

Canada : (905) 669-0114

Du lundi au vendredi, de 8h00 à 16h30

Vous recevrez des instructions précises sur la façon de faire réparer votre appareil.

Le service pourra aussi répondre à toute question générale que vous aimeriez poser au sujet des appareils.

Avant de téléphoner au service à la clientèle, veuillez disposer du numéro du type de votre appareil KRUPS.

Vous devez posséder cette information avant de téléphoner à notre service à la clientèle pour nous permettre de mieux répondre à vos questions. Le numéro du type se trouve sur le fond de votre appareil.

Le présent est du type n° FDD5.

Veuillez adresser toute correspondance générale à :

USA :KRUPS North America, Inc.
P.O. Box 3900
Peoria, IL 61612

Canada : Service KRUPS
20 Caldari Rd
Concord, Ontario
L4K 4N8